Live View

You will see your camera images displayed in a grid format.

On initial setup the default username and password is, User: 1, Password: 1

